



## POWERS CONTROLS™


### Pneumatic Damper Actuator Quick Reference Guide

- No. 3 Damper Actuator
- No. 4 Damper Actuator
- No. 6 Damper Actuator
- LC Motor Damper Actuator



Scan code to download  
this reference guide

# POWERS™ No. 3 Pneumatic Damper Actuators



## Key Product Documentation

(click on desired document title to open and download)

[No. 3 Damper Actuator Technical Instructions](#)

Features and benefits, application, sizing and part numbers

[No. 3 Damper Actuator Installation Instructions](#)

Installation instructions, tools and pre-requisites

[Actuator Positioning Relay Technical Instruction](#)

Features and specifications, application and operation information

[No. 3 Positioning Relay Mounting Kit Instructions](#)

Mounting kit installation instructions


[Actuator Positioning Relay Calibration Specification](#)

Installation and calibration instructions

## POWERS™ No. 3 Actuator Part Numbers

Type	l 3-7 psi	n 5-10 psi	t 8-13 psi	Ü Positioning Relay
①	331-4310	331-4510	331-4810	331-4809
②	331-4313	331-4513	331-4813	-
③	331-4314	331-4514	331-4814	-
④	331-4331	331-4531	331-4831	332-4831
⑤	331-4312	331-4512	331-4812	-
⑥	331-4311	331-4511	331-4811	332-4811

# POWERS™ No. 4 Pneumatic Damper Actuators



## Key Product Documentation

(click on desired document title to open and download)

[No. 4 Damper Actuator Technical Instructions](#)

Features and benefits, application, sizing and part numbers

[No. 4 Damper Actuator Installation Instructions](#)

Installation instructions, tools and pre-requisites

[Actuator Positioning Relay Technical Instruction](#)

Features and specifications, application and operation information

[No. 4 Positioning Relay Mounting Kit Instructions](#)

Mounting kit installation instructions


[Actuator Positioning Relay Calibration Specification](#)

Installation and calibration instructions

## POWERS™ No. 4 Actuator Part Numbers

Type	I 3-7 psi	£ 3-13 psi	n 5-10 psi	t 8-13 psi	μ Hesitation 2-3, 8-13
①	331-2904	331-2905	331-2906	331-2961	331-2909
②	331-2929	331-2930	331-2931	331-2968	-
③	-	-	-	-	331-2927
④	-	-	-	-	331-2974
⑤	-	331-3018	-	331-3017	-
⑥	331-3000	331-3001	331-3002	331-2973	331-3004
Ü Positioning Relay Models					
		⑪	⑫	⑬	
		332-2961	332-2968	332-2973	

# POWERS™ No. 6 Pneumatic Damper Actuators and LC High-Force Motor



## Key Product Documentation

(click on desired document title to open and download)

[No. 6 Damper Actuator Technical Instructions](#)

Features and benefits, application, sizing and part numbers

[No. 6 Damper Actuator Installation Instructions](#)

Installation instructions, tools and pre-requisites

[LC Motor 331-2882 Technical Instructions](#)

Features and benefits, application, sizing and part numbers

[LC Motor 331-2882 Installation Instructions](#)

Installation instructions, tools and pre-requisites

[Tandem Mount 331-3070 Technical Instructions](#)

Features and benefits, application, sizing and part numbers

[Actuator Positioning Relay Technical Instruction](#)

Features and specifications, application and operation information

[No. 6 Positioning Relay Mounting Kit Instructions](#)

Mounting kit installation instructions

[Actuator Positioning Relay Calibration Specification](#)

Installation and calibration instructions

## POWERS™ No. 6 Actuator Part Numbers

Type	S 3-7 psi	E 3-13 psi	t 8-13 psi	U Positioning Relay
①	331-2793	331-2794	331-3060	-
②	-	-	331-2988	-
③	331-2857	331-2858	331-2856	332-2856
④	331-3012	331-3013	331-3011	332-3011
⑤				331-3070
⑳				331-2882